Write Way® Directional Sign





Dual-sided dry-erase board can be positioned to point people in the right direction. Simply write your message on the attention-getting arrow-shaped surface and position the sign up, down, left or right. Change your message as often as needed. The dualsided dry-erase board is ideal for use with magnets and allows viewing from either side. Arrow adjusts + or - 45°. 18" wide base can be weighted with water or sand for stability. Molded construction with UV inhibitors for indoor or outdoor use. Black finish. Easy assembly required.

Model	Description	WxDxH	Snip Weight
4173BL	Write Way Directional Sign	25 ¹ / ₂ x 17 ³ / ₄ x 64 ¹ / ₄ "	10 lbs.

Discount Code B



