

# ***Pledge® Multi-Surface Aerosol***



## **Product Characteristics**

- Comes in Aerosol (Lavender, Rainshower and Fragrance Free 275g), 470mL Trigger and Wipes (25) formats.
- Cleans wood (painted, glossy, and matte finish), glass and mirrors, appliances, countertops, stainless steel, metal, chrome, sealed marble & granite, electronics and plastic.
- Do not use on UNSEALED surfaces.

## **Key Benefits**

- Cleans and dusts all surfaces without streaks or smeary residue

## **Ingredients/Instructions**

- Aerosol: 1) shake well before use. 2) Turn top of nozzle counterclockwise to lock. 3) Hold can upright and spray about 8 inches from surface. 4) Wipe immediately with a clean cloth.
- Trigger: 1) shake gently before use 2) turn spray nozzle to ON position 3) simply spray and wipe with a soft cloth or paper towel until surface is clean
- Wipe: 1) Open pouch by peeling back seal. Reseal pouch after each use to retain moisture. Store in a cool location. 2) pull wipe from pouch and use to clean surfaces. 3) when wipe gets dirty or dries out, discard.

## **Frequently Asked Questions & Answers**

**1- Can Pledge® Multi Surface be used with other household cleaners?**

**A:** No.

**2- Can Pledge® Multi Surface be used on the floor?**

**A:** No, it may leave it slippery

**3- How do I get a higher shine on the wood?**

**A:** For higher shine on your wood, use Pledge® Furniture Polish

**4 - What is the difference between Multi Surface Aerosol efficacy on wood vs. our base aerosol line?**

**A:** While both SKUs do a fine job cleaning and conditioning wood, the base aerosol formula produces a higher shine on wood compared to multi-surface aerosol. The Multi Surface aerosol performs well on glass and contains an Anti Static formula that is great for cleaning electronics. Base Pledge® aerosol is not intended for these surfaces.